
Dry Electrode Arduino OLED Display Kit



—, Bill of Materials

```
dry Electrode muscle electrical module × 1;
module audio cable × 1;
strap × 1;
Arduino UNO × 1;
Arduino shield plate × 1;
0.960LED × 1;
3p terminal line × 1;
USB cable × 1;
```

二、Software configuration

1. Arduino IDE (recommend 1.8.2 and above)

(A file named How do I install Arduino IDE correctly.pdf can be found in the zip package)

2. Arduino driver

(A file named CH341SerSetup.rar can be found in the zip package)

三、Wiring

1. Description

- ① Arduino the shield and the Arduino UNO are directly inserted
- ② the OLED display screen is inserted into the position of oled in the upper left corner of the Arduino shield
- ③ the EMG module and the Arduino Shield are connected through Dupont line.




pin description and wiring:

myoelectric module Arduino shield

- 1 (power input negative pole) --> GND
- 2 (power input positive pole) --> 5V
- 3 (analog signal output 0~3.3V) --> A0
- 4 (PJ-342 Dry electrode interface)

2. Wiring diagram display



四、Burning code

1. Copy the code

copy the code below to the Arduino IDE.

```
typedef struct // Curve parameter
 float Draw Buf[128]; // Curve data cache
 float Draw Min;
                   // The minimum value of the cached data is in percentage
 float Draw_Max; // The maximum value of cached data
} DrawCurve;
                    // Curve parameter
static _DrawCurve DrawCurve;
void PlotDataInput(_DrawCurve *Draw, float val) {
 uint8_t i;
 for (i = 1; i < 128; i++) {
   Draw->Draw_Buf[i - 1] = Draw->Draw_Buf[i];
 Draw->Draw Buf[127] = val;
 if (Draw->Draw_Buf[127] > 1)
   Draw->Draw Buf[127] = 1;
 else if (Draw->Draw Buf[127] < 0)
   Draw \rightarrow Draw Buf[127] = 0;
* Wuxi Sichiray Co., Ltd
 * The AliExpress store: Sichiray Store
* Shop website: https://sichiray.aliexpress.com/store/1100735731
 * Mailbox: sichiraywuxi@gmail.com
Draw->Draw_Max = 0;
 Draw->Draw Min = 1;
 for (i = 0; i < 128; i++) // Gets the maximum and minimum range
   if (Draw->Draw_Min > (Draw->Draw_Buf[i])) {
     Draw->Draw Min = Draw->Draw Buf[i];
     Draw->Draw Min = (float) ((uint8 t) (Draw->Draw Min * 100) / 5) / 20;
     if (Draw->Draw_Min < 0)
```


```
Draw->Draw_Min = 0;
      if ((Draw->Draw Max - Draw->Draw Min) < 0.05)
        Draw->Draw Max = Draw->Draw Min + 0.05;
    } else if (Draw->Draw Max < Draw->Draw Buf[i]) {
      Draw->Draw_Max = Draw->Draw_Buf[i];
      Draw->Draw_Max = (float)((uint8_t)(Draw->Draw_Max * 100) / 5 + 1) / 20;
      if (Draw->Draw Max > 1.0)
        Draw \rightarrow Draw Max = 1.0;
      if ((Draw->Draw_Max - Draw->Draw_Min) < 0.05)
        Draw->Draw_Min = Draw->Draw_Max - 0.05;
void PlotDataPrint(_DrawCurve *Draw, int fllor, int upper, int lineColor) {
  for (int x = 1; x < 128; x^{++}) {
    float k = (upper - fllor) / (Draw->Draw_Max - Draw->Draw_Min); // Y-axis scaling
factor
    float last y = upper - ((Draw->Draw Buf[x - 1] - Draw->Draw Min) * k);
    float now y = upper - ((Draw->Draw Buf[x] - Draw->Draw Min) * k);
    oled.drawLine(x - 1, last_y, x, now_y, lineColor);
void setup() {
#ifndef DEBUG
  oled.begin(SSD1306 SWITCHCAPVCC, OLED Address);
  oled.clearDisplay();
#else
  Serial. begin (115200);
#endif
```

```
delay(100);
void loop() {
 static uint16_t value = 0;
 value = analogRead(A0);
#ifndef DEBUG
 PlotDataInput(&DrawCurve, value / 1024.0); // Incoming data
 oled.clearDisplay();
 PlotDataPrint(&DrawCurve, 10, 60, WHITE); // Print curve
 oled.display();
#else
 Serial. println(value);
 delay(5);
#endif
* Wuxi Sichiray Co., Ltd
* The AliExpress store: Sichiray Store
* Shop website: https://sichiray.aliexpress.com/store/1100735731
* Mailbox: sichiraywuxi@gmail.com
```

select SCM and port

find the port of CH340 from the Device Manager and select the corresponding serial port.

(A file named how do I view the serial port.pdf can be found in the zip package)



3. compile and upload.

After the code is uploaded successfully, wear the electrode correctly to display the waveform. Wipe the electrode and skin with water before wearing it.

Key point: when using it, you must disconnect the power supply of the notebook computer to produce the correct waveform.

6. Operate videos

(A file named videol.mp4 can be found in the zip package)


- •place the sensor in the position where muscle activity needs to be detected, and then calibrate it to accurately count muscle activity, such as push-ups counting and dumbbell meter.
- •it can also be used for human-computer interaction in several fitness occasions.

五、FAQ

1. where can dry electrodes be placed on the arm? Do you have any requirements?

The three-metal dry electrode plate is adopted, which does not need to pay attention to the reference level, but only needs to keep the electrode plate consistent with the muscle direction.

For more information about the location, see the following figure:



2. the serial port plotter has no waveform after burning the code.

Set baud rate to 115200.

3. wiring is not based on the color of the wire, but in the order of the interface

the order is $gnd \rightarrow 5v \rightarrow a0$.

4. waveform no response

in this case, check several solutions:

- •whether it is attached to the position of muscle activity;
- •whether it is tied tightly;
- •whether the laptop power is unplugged;
- •whether the connection interface is plugged tightly;
- •wipe the electrode and skin with water.

5. can I connect the oscilloscope?

No. The Oscilloscope has power interference.